

# ***Street Magic***<sup>®</sup> ***RIPS***<sup>™</sup> Kit Install Instructions

*If you are going to be using a RIPS™ Kit with your BRIGHTSIDES™ hook the wires as follows.*

The **RIPS**<sup>™</sup> unit has 3 wires on one end and two wires on other end. Using the Posi-Lock connectors supplied with your **RIPS**<sup>™</sup> kit hook the wires on two wire end of **RIPS**<sup>™</sup> to the **BRIGHTSIDE**<sup>™</sup> wires as follows.

The **RED** wire from **RIPS**<sup>™</sup> unit to the **White** wire from the **BRIGHTSIDE**<sup>™</sup>.

The **BLACK** wire from **RIPS**<sup>™</sup> unit to the **BLACK** wire from **BRIGHTSIDE**<sup>™</sup>.

For the three remaining wires from the **RIPS**<sup>™</sup> unit, hook them to the main harness using Posi-Tap connectors as follows.

The **RED** wire from **RIPS**<sup>™</sup> unit to the wire in **PORT #2** in connector.

The **ORANGE** wire from **RIPS**<sup>™</sup> unit to the wire in **PORT #4** in connector.

The **BLACK** wire from **RIPS**<sup>™</sup> unit to the wire in **PORT #5** in connector.

If you have any questions on how to use any of the Posi- Lock products, please see **[www.posi-lock.com](http://www.posi-lock.com)**