

## Street Magic RS Rear Brightsides™ Installation Instructions.

- 1) Remove the 7 torx screws that hold the rear under-tail cover in place to gain access to wiring.
- 2) Using a small screwdriver or other suitable pry tool remove reflectors from rear fender struts. **(Put you Picture # 4178 here)**
- 3) After removing all glue and tape residue drill a 3/16” hole in fender support to pass Brightsides™ wire through. **(Put you Picture # 4180 here)**
- 4) Treat fender strut area with enclosed 3M promoter pad let dry 1 minute. Once dry pass wire from remover backing from tape on the back side of the Brightsides™ and pass the wire through the hole firmly pressing the Brightside™ into place. **(Put your pictures #4183 and 4185 here)**
- 5) Next using 3 of thre supplied 3M wire blocks place two blocks inside of the fender strut and one block onto rear swing arm as shown to guide wire forward to under-tail panel ‘s front edge. Use zip ties to hold wire to the 3M blocks. **(Put your pictures #4188, #4192 #4193 and #4194 here)**
- 6) Repeat procedures 1 through 5 to install the other Brightsides™ onto the remaining fender strut.
- 7) Locate the two wire connector for the rear plate light and using supplied Posi-Tap connectors attach the red wires from the Brightsides™ to the orange wire in this connector and the black wire from the Brightsides™ to the black wire in this connector. **(Put your picture #4198 here)**
- 8) If you are using a RIPS™ unit to make your Brightsides™ both a running light and turn signal hook the wires as follows below.
- 9) Using the supplied Posi-Tap connectors, attach the long orange wire from the 3 wire end of the RIPS™ unit to the positive wire going to the left side turn signal. Then attach the black wire from the 3 wire end of the RIPS unit to the black (negative) wire going to the plate light. Attach the red wire from the RIPS™ 3 wire end to the orange (positive) wire going to the plate light. Repeat these steps for the right side Brightsides™ tapping into the right turn signal wire as needed. **.(Put your picture #4196 and #4197 here)**
- 10) Using the supplied Posi-Lock connectors attach the wires from the Brightsides™ to the 2 wire end of the RIPS™ units as follows. Attach the red wire from Brightsides™ to the red wire from RIPS™ unit’s 2 wire end, and the black wire from the Brightsides™ to the black wire from the RIPS™ unit’s 2 wire end.
- 11) Test operation and reinstall under-tail panel.