

# ***Street Magic*** Can-Am Spyder

## WAKE UP Install Instructions

- 1) Remove rear under tail cover by removing the 7 torx head screws.
- 2) Locate and unplug both tail light 3 port connectors.
- 3) Plug connectors from WAKE UP unit between connectors.  
(does not matter which connector goes to which side)
- 4) Test operation
- 5) Re-install under tail cover.

\*\*\* NOTE: 2 SECOND OFF CYCLE REQUIRED BEFORE FLASH WILL FULLY REPEAT \*\*\*